


Bella Vista exhalation filter



Wrong place to put the exhalation filter.

Expiratory flow leaves here

Filter should be placed before the exhalation valve.

All expiratory flow leaves the vent below the exhalation valve. See pic above.

The expiratory connection with the vent is a "blind" end, no flow goes this way